



LIST OF SPARES

Item No	Description	Pack	R3385TTS	R3599TTS	R3453	R3596
1	Cylinder Block	1	X9146	X9146	X9146	X7226
2	Motor Assembly	1	X4026	X4026	X4026	X4026
3	Motor retainers	Pack	X9079	X9079	X9079	X9079
4	Valve Gear Set	Set	X9147	X9147	X9147	X9147
5	Loco wheel/Axle Set	Set	X9089	X9089	X9089	X9089
6	Bogie Assembly	1	X9078	X9078	X9078	X9078
7	Coupling Rods	Set	X9087	X9087	X9087	X9087
8	Loco Chassis Bottom	1	X9081	X9081	X9081	X9081
9	Gear Set	Set	X8849	X8849	X8849	X8849
10	Draw Bar	1	X6235	X6235	X6235	X6235
11	PCB Holder	1	X7225	X7225	X7225	X7225
12	Couplings	10	X6235	X6235	X6235	X6235
13	Tender Chassis Assy	1	X7227	X7227	X7227	X7227
14	Tender Wheels	Set	X9082	X9082	X9082	X9082
15	Tender chassis bottom + screws	1	X8949M	X8949M	X8949M	X8949M
16	Tender conection	1	X9958	X9958	X9958	X9958
17	Wires to tender conection	1	X6113	X6113	X6113	X6113
18	Decoder and Speaker	Pack	X12297	X12297	N/A	N/A
NI	Assy Pack		X4524	X4524	X4524	X4524