



LIST OF SPARES

Item	Description	Pack	R3709/X	R3711/X	R3713/X
1	Motor / Flywheel	1	X7512	X7512	X7512
2	Motor cradle and worm pinion cover	Set	X7513	X7513	X7513
3	Cylinder Block	1	X7514	X7528	X7529
4	Coupling rods / Valve gear	Set	X7515	X7530	X7531
5	Gears Set	Set	X7516	X7516	X7516
6	Worm pinion / Bearings spacers / Gear Cover	1	X7518	X7518	X7518
7	Loco wheel set	Set	X7519	X7519	X7519
8	Bogie complete with bracket	1	X7520	X7520	X7520
9	Drawbar	1	X7521	X7521	X7521
10	Loco chassis bottom pick ups	1	X7522	X7522	X7522
11	Dummy pony wheels	1	X7523	X7523	X7523
12	Tender Assy	1	X7524	X7532	X7533
13	Tender Wheel Set	Set	X7525	X7525	X7525
14	Tender chassis bottom and Pick-ups	1	X7526	X7556	X7526
15	Loco Chassis Pick-ups	1	X7527	X7527	X7527
16	Electrical Tender Socket	1	X9958	X9958	X9958
17	Wires to tender plug	1	X6113	X6113	X6113
18	PCB	1	X9084TC	X9084TC	X9084TC
NI	ASSY BAG	Pack	X13587	X13576	X13588