



### LISTA RICAMBI / ERSATZTEILLISTE / LIST OF SPARES

N° di parte Art.Nr. Item No.	Descrizione Bezeichnung Description	Confezione Pckg. Pack	
1	Confezione complessivo/Respingente Baugruppen/Puffer-Satz Assembly/Buffer Pack	pack	HR2172/1
2	Confezione attacco Kupplungssatz Coupling pack	pack	HR2172/2
3	Trasmissione Antrieb Drive Unit	1	HR2172/3
4	Carrello (senza ruote) D rehgstell (ohne Räder) Bogie Assembly (without wheels)	1	HR2172/4
6	Scheda circuito stampato luci Lichtleiterplatte Lights board	1	HR2172/6
7	Scheda principale a circuiti Stampati Hauptleiterplatte Main PCB board	1	HR2172/7
8	Confezione motore Motor-Satz Motor Pack	1	HR2172/8
9	Confezione Albero Universale Universal-Wellensatz Universal shaft pack	pack	HR2172/9
11	Pneumatici Trazione Haftreifen Traction Tyres Pack	set	HR2172/11
13	Azionamento set ruote Radsatz für Antrieb Wheel set (drive unit)	1	HR2172/13



