






LISTA DE RECAMBIOS / LIST OF SPARES

Número Number	Descripción Description	Ref. repuesto Spare part ref.
1	Accesorios techo Roof accessories	ER3455/01
2	Rejillas techo (1 + 1) Roof grills (1 + 1)	ER3455/02
3	Aire acondicionado Air conditioning	ER3455/03
4	Antena / Aire acondicionado cabina Aerial / Cabin air conditioning	ER3455/04
5	Rejillas laterales Side grills	ER3455/05
6	Set limpiacristales y manivela Windscreen wipers and handle set	ER3455/06
7	Set faldón Flap set	ER3455/07
9	PCB PCB	ER3463/09
10	Interior de coche motor Interior part of motor coach	ER3455/10
11	Tapa altavoz Speaker cover	ER3455/11
12	Set difusor luces Light diffusers set	ER3455/12
13	Set interior cabina 1 Cabin 1 interior set	ER3455/13
14	Chasis Chassis	ER3463/14
15	Accesorios chasis Chassis accessories	ER3455/15
16	Set motor Motor set	ER3463/16
17	Cardan Cardan	ER3455/17
18	Tapa sinfín Worm gear cover	ER3463/18
19	Sinfín Worm gear	ER3455/19
20	Caja engranajes Gear box	ER3463/20
21	Tomas de corriente de bogie 1 Current pick-ups of bogie 1	ER3455/21
22	Set bogie 1 Bogie 1 set	ER3455/22
23	Set engranajes y ejes Gears and axles set	ER3455/23
24	Set ejes motriz DC DC drive axles set	ER3455/24
25	Set ejes motriz AC AC drive axles set	ER3455/25
26	Base bogie DC DC bogie base	ER3455/26
27	Base bogie AC AC bogie base	ER3455/27
28	Patin AC AC Pick-up shoe	ER6850A
29	Tornillo patin AC AC Pick-up shoe screw	ER6851
30	Set de burlate y enganche Bellow and coupler set	ER3463/30
32	Set brazo de enganche Coupler arm set	ER3463/32
33	Set bogie 2 Bogie 2 set	ER3455/33
34	Tomas de corriente de bogie 2 Current pick-ups of bogie 2	ER3455/34
35	Base bogie 2 Bogie 2 base	ER3463/35
36	Set ruedas sin engranaje DC DC wheels set without gears	ER3455/36
37	Set ruedas sin engranaje AC AC wheels set without gears	ER3455/37



LISTA DE RECAMBIOS / LIST OF SPARES		
Número Number	Descripción Description	Ref. repuesto Spare part ref.
38	Tapa bogie Bogie cover	ER3455/38
39	Bogie completo DC DC complete bogie	ER3463/39
40	Bogie completo AC AC complete bogie	ER3464/40
44	Conector con cables Wired connector	ER3463/44
45	Bogie sin motorizar Dummy bogie	ER3455/45
46	Set interior cabina 2 Cabin 2 interior set	ER3455/46
48	Set 2 Pantógrafos Pantograph set	ER3463/48
49	Rejillas laterales coche intermedio pantógrafo Intermediate pantograph coach side grills	ER3455/49
50	Contacto pantógrafo Pantograph contact	ER3455/50
51	Conectores con cable coche intermedio Intermediate coach wired connector	ER3463/51
52	Accesorios bajos coche pantógrafo Pantograph coach lower part accessories	ER3455/52
55	Aros de adherencia Grip rings	ER3455/55
56	Bogie DC DC Bogie	ER3463/56
57	Bogie AC AC Bogie	ER3463/57
	Decoder digital 21 pins Digital decoder with 21 pins	ER301/CIVIA
	Decoder Sonido 21 pins Sound Decoder with 21 pins	ER301SCIVIA-21

