





## Fitting add on detail parts

## Cab handrail (if applicable)




Cab handrail fits here - locos with running numbers 76000 - 76044 only

# Front footsteps (for larger curves only)




## Injector pipes



Add-on pipe fits *inside* that fitted to loco - suitable for static model only

# Cylinder draincocks and alternative valve guides





## BR Standard Class 4 2-6-0

Thank you for your choice of the Graham Farish BR Standard Class 4 2-6-0 locomotive.

## Running in

The mechanism of this model requires running in (without a load) for approximately 1 hour in each direction at moderate speed.

#### Curves

This locomotive is suitable for use on track with curves of second radius (approx. 10½ inches / 260 mm) or greater

## Tender body removal

Remove the two screws at the rear of the chassis as indicated on the diagram.

## DCC Decoder fitting to non DCC fitted loco

This model has an 6-pin NMRA/NEM 651 socket for a decoder with an appropriate plug Align the decoder as indicated.

It's advisable to run in as above using a DC power supply before moving on to fit a DCC decoder

#### Lubrication

When required, sparingly lubricate the motor bearings using plastic compatible light oil and the gear train with model grease. Suitable lubricants are Bachmann E-Z Lube item 99984 or Woodland Scenics 'HobbyLube' Lite Oil item HL654.

### Add-on detail parts.

The pack contains: Vacuum pipes .

Front steps

Alternative short loco/tender drawbar: suitable for large

radius curves only


Cylinder draincocks

Inner injector (for display model only)

Alternative valve guides (for display model only)

Cab handrail (if appropriate to model)








### Parts


1	Motor	7	Cylinders / motion
2	Drawbar	8	Front bogie
3	Pickups	9	Tender baseplate
4	Driving wheels	10	Tender underframe
5	Gears	11	Loco baseplate
6	Tender wheels		'


Replacement parts available from retailers

Couplings item 379-402 Traction tyres item 379-420

Location of tender shell securing screws







Carefully remove the blanking board above the motor and replace with a decoder with a NMRA/NEM 651 6-pin fitting.

# Bachmann Europe Plc

Moat Way, Barwell, Leicestershire, LE9 8EY 01455 841756 www.bachmann.co.uk 4MT 2-6-0 rev 1 08/09 F7265-IS001