



## Triang (AAILUAVE











XT.70

T.96/1	Body complete with cab	XT.75 XT.77	Non-powered Bogie Axle Assembly for Non-	ST.4043 ST.4047	Non-powered Bogie Axle Coupling Fixing Rivet (not
XT.12	windows Coupling Unit (not shown	X1.11	powered Bogie XT.75 (com-		shown separately)
X1.1.2	separately)		prising 2—ST.2067, 1—ST.		Collector Unit (L/H)
XT.27	Brush Arm and Brush		4043)		Collector Unit (R/H)
XT.70	Power Bogie	XT.113	Non-powered Bogie Chassis	ST.5082	Keeper Plate
XT.71	Armature Assembly (including	ST.1032	Pole Piece	ST.6022	Magnet
×1.//	commutator, worms and	ST.1040	Pivot Bracket	ST.6023	Brush Spring
		ST.1045	Wheel for Power Bogie	ST.6027	Window Strip
	bearings)			S.1003	Keeper Plate Securing Screw
XT.72	Axle Assembly for Power	ST.2044		5.1015	Pivot Pin
	Bogie XT.70 (comprising 2-	ST.2046	Top Housing	5.1027	Brush Spring Post Securing
	ST.1045, I—ST.2044)	ST.2047	Dummy Wheel Unit	3.1027	
XT.73	Power Bogie Chassis (com-	ST.2067	Wheel for Non-powered Bogie		Nut
	prising Chassis Casting ST. 1033,	ST.2070	Underframe	S.1039	Roof Fixing Screw
	Coupling Unit XT.12, Coup-	ST.2072	Roof Screw Boss	S.1053	Magnet Screw
	ling Rivets ST.4047 and Adhes-	ST.2163	Roof Moulding	S.5227	Pivot and Magnet Screw Nut
	ion Magnet ST.1053)	ST.4031	Brush Spring Post	S.5230	Capacitor
	ion Hagner St.1055)	ST.4035	Pivot Screw		
		31,4033	I II De ani ani		

Modifications are made to Tri-ang Railways models from time to time. If a spare part is required which does not coincide with the illustration, a full description should be given and, if necessary, a sketch or sample should accompany the order.

PRINTED IN ENGLAND

S.2023 Thrust Bush

spare parts if required.

They can be supplied as individual

