




LIST OF SPARES

Item No	Description	Pack	R3850	R3719X	R3851	
			R3719	R3723X	R3725	R3725X
1	Motor retainers with screws	Set	X7496	X7496	X7496	X7496
2	Motor flywheel worm pinion assy	1	X7497	X7497	X7497	X7497
3	Cylinder Block / Piston rod	1	X7498	X7498	X7510	X7510
4	Gear Shaft Assembly	1	X7499	X7499	X7499	X7499
5	Coupling rods and screw spacers	Set	X7500	X7500	X7500	X7500
6	Loco Wheel / Axle set	Set	X7501	X7501	X7501	X7501
7	Loco Chassis bottom	1	X7502	X7502	X7502	X7502
8	Bogie Assembly	1	X7503	X7503	X7503	X7503
9	Pony truck assembly	1	X7504	X7504	X7504	X7504
10	Loco Pick-ups	1	X7505	X7505	X7505	X7505
11	Couplings	10	X9289	X9289	X9289	X9289
12	PCB holder + blanking plug	Pair	X7507	X7507	X7507	X7507
13	Chassis assembled parts	Pack	X7508	X7508	X7508	X7508
14	Chassis assembled parts	Pack	N/A	N/A	N/A	N/A
NI	Assy Pack	Pack	X13243	X13243	X13243	X13243
NI	Decoder	1	N/A	X5749B	N/A	X5749B