




LIST OF SPARES					R3986 R3987 R30132 R30396	R3988	R30133	R30132TXS	R30351
Item No	Description	Pack							
1	Motor Retainers	Pack	X1025	X1025	X1025	X1025	X1025	X1025	X1025
2	Motor / Flywheel	1	X1026	X1026	X1026	X1026	X1026	X1026	X1026
3	Cylinder Block	1	X1027	X1043	X1027	X1027	X1027	X1027	X1027
4	Motion Bracket / Valve Gear / Coupling Rods	Pack	X1028	X1028	X1028	X1028	X1028	X1028	X1028
5	Gear Set	Set	X1029	X1029	X1029	X1029	X1029	X1029	X1029
6	Loco Wheel Set	Set	X1030	X1030	X1030	X1030	X1030	X1030	X1030
7	Loco chassis bottom	Pack	X1032	X1032	X1032	X1032	X1032	X1032	X1032
8	Pony Truck Assy	Pack	X1033	X1033	X1033	X1033	X1033	X1033	X1033
9	Drawbar	1	X1034	X1034	X1034	X1034	X1034	X1034	X1034
10	Loco Pick-up PCB	1	X1035	X1035	X1035	X1035	X1035	X1035	X1035
11	Firebox PCB	Set	X50160	X50160	X50160	X50160	X50160	X50160	X50160
12	Universal Joint / Worm bearings	Set	X1036	X1036	X1036	X1036	X1036	X1036	X1036
13	Tender Chassis & Contacts Assy	Pack	X1037	X1037	R30133/13	X1037	R30351/13		
14	Tender Wheel Set	Pack	X1038	X1038	X1038	X1038	X1038	X1038	X1038
15	Tender underframe Assy	Pack	X1039	X1039	X1039	X1039	X1039	X1039	X1039
16	Coupling Pack	Pack	X9289	X9289	X9289	X9289	X9289	X9289	X9289
17	Sugarcube Speaker	1	X1044	X1044	X1044	X1044	X1044	X1044	X1044
18	21 Pin PCB and Blanking Plug	1+1	X1040	X1040	X1040	X1040	X1040	X1040	X1040
19	Loco to tender Wires and Plug	1	X50025	X50025	X50025	X50025	X50025	X50025	X50025
20	Tender Plug	1	X9958	X9958	X9958	X9958	X9958	X9958	X9958
NI	Assy Pack	Pack	X14665	X14665	R30133/21	X14665	X14665	X14665	X14665
NI	TXS Blank Decoder	1	N/A	N/A	N/A	N/A	X14655	N/A	N/A