
Triang HORNBY



X.67 X.112 X.116 X.171 X.564 X.565 X.592 X.593 X.594	Locomotive Body (complete with Windows, Buffers and Route Labels) Brush Arm and Brush Armature Assembly (including commutator and worms) Axle Assembly Mk. 3 Coupling Unit Non-powered Bogie Pantograph Chassis and Weight Assembly T.V. Suppressor with Lead and Brush Clip Collector Assembly (with spring and lead)	X.595 X.606 X.664 X.3169 S.1023 S.1055 S.1070 S.1090 S.2003 S.2229 S.2238 S.2239 S.2271 S.3120	Non-powered Bogie Frame Assembly Switch Assembly Brush Spring and Insulator Power Bogie Body Securing Screw Magnet Screw Coupling Screw (3/16") Switch Securing Screw Standard Rolling Stock Axle Large Round Headed Buffer Spacing Collar Power Bogie Pivot Pin Collector Securing Screw Brush Gear Diaphragm	S.3121 S.3127 S.3368 S.4044 S.4225 S.5096 S.5097 S.5098 S.5100 S.5104 S.5108 S.5141 S.5147 S.9117	Brush Gear Return Spring Spring Clip Collector Spring Top Mounting Bracket Power Bogie Main Frame Thrust Ball Nut for Switch Assembly Wheel for Non-powered Bogie Bogie Eyelet Spherical Bearing Felt Lubricating Pad Pole Piece Magnet Pantograph Lead
--	--	---	--	--	---

Modifications are made to Tri-ang Hornby models from time to time. If a spare part is required which does not coincide with the illustration, a full description should be given and, if necessary, a sketch or sample should accompany the order. We do not undertake to supply separate components for the parts listed with an X prefix, unless a separate 5 part number is shown.

PRINTED IN ENGLAND

5.2271