FARISH

Thank you for your choice of the Graham Farish Class 150 diesel multiple unit.

Running in

The mechanism of this model requires running in (without a load) for approximately 1 hour in each direction at moderate speed.

Curves

This locomotive is recommended for use on 12" radius curves but will operate on 9" radius curves.

Body removal

The bodyshell clips over the chassis and can be removed by carefully easing away from the chassis.

Lubrication

When required, sparingly lubricate the motor bearings using plastic compatible light oil and the gear train with model grease. Suitable lubricants are Bachmann E-Z Lube item 99984 or Woodland Scenics 'HobbyLube' Lite Oil item HL654.


DCC Decoder fitting

The model has a NMRA/NEM 651 6-pin decoder socket in both power and trailer cars.

Follow the instructions supplied with the decoder. Remove the blanking board and

Bachmann Europe Plc

Moat Way, Barwell, Leicestershire, LE9 8EY 01455 841756 www.bachmann.co.uk Class 150 rev 1 12/08 F7132-ISO01



fit the decoder, aligning as shown. We recommend that the model is run in first using a DC supply before fitting a decoder.

Sound decoder / loudspeaker fitting

Space is provided at the gangway end of the power car for loudspeaker to be used in conjunction with a suitably sized sound decoder. A second speaker enclosure is included which may be fitted in place of part of the seating moulding towards the centre of the car.


Snowplough and cosmetic BSI coupler

These fit to the front of chassis. They are suitable for use only as an alternative to the functional coupler on the bogie.



Class 150 DMU

Parts



Parts are subject to availability.